

Your Tru-Nord Compass is a precision instrument, specifically designed for use in wilderness areas, day or night where an accurate, dependable quick reading compass is essential. ****North Pointer has luminous glow in the dark paint as well as dial. Charge with flashlight or LED light to make brighter**** Observe the following suggestions in order to obtain the full benefit of the special features built into your Tru-Nord Compass.

Stand in a natural position. Pin compass on left side (shooting gun from right side) near coat or shirt Pocket. Models 200 C / 200CB apply. When compass is properly pinned dial will float freely and can be read at a glance as you walk. Remove all metallic articles from pockets near compass. Compass should be worn opposite side in which you shoulder your gun.

If using Tru-Nord's Zipper Pull Model 150C applies, make sure no metal is close enough to make compass not operate.

Before entering a strange or unknown area STOP—check your compass for direction of intended travel and note directions of all roads, trails or other landmarks. Observe carefully, establishing a mental picture of your starting point. As you proceed, observe your compass frequently...this will keep directions clearly in your mind.

As an extra precaution, observe starting point as mentioned above. Then turn your back to the direction of intended travel and with a pencil press a strong mark on your compass rim at the end of the North Pointer. **You are creating a Back Azimuth.** Should you later become confused or wish reassurance, calming face direction so that the North Pointer is at the pencil mark. In most cases this act will clarify direction should you wish to return to your starting point. Walk keeping pencil mark at end of NORTH POINTER in order to return to your starting point.

For repairs or service send compass with \$ 5.00 Postage Fee to Tru-Nord Compass, 615 Quince Street, Brainerd, MN. 56401.

<http://www.trunord.com>

